

# THE NEW EASY UP™ DECONTAMINATION SHOWER

## LIGHTER. LOWER PRICED. LESS SPACE.

The new S4000EU Modular Decontamination Shower from Abatement Technologies provides contractors with the most economical and user-friendly metal shower available. When assembled, Easy Up is large enough to fit tall workers. When disassembled, it is small enough and light enough for a worker to hand carry like a briefcase or suitcase.

### 40% LIGHTER!

At only 41 pounds, the new Easy Up S4000EU modular shower is almost 25 pounds lighter than any other metal shower unit. That makes it much easier to hand-carry using the attached handle, and eliminates the need for small casters that can be easily damaged.

### EASY TO TRANSPORT & STORE

Easy Up is quickly disassembled without tools. The floor module functions as a compact carrying case for the multi-piece, interlocking corner poles. The curtains, showerhead, and mixing valve are attached to the top module, which functions as the lid for the carrying case. The top and bottom modules then latch securely together.

### FAST SETUP

One person can set up the Easy Up shower in just a few minutes. Simply separate the top and floor modules, assemble the modular corner poles into the floor module, and insert the top module over the poles.

### QUALITY & RELIABILITY

Abatement Technologies has remained the most trusted name for abatement equipment for over 21 years.

### SPECIFICATIONS

Weight: 41 pounds  
Length & Width: 30"  
Assembled Height: 81"



 **ABATEMENT  
TECHNOLOGIES®**  
Technologically Advanced Air Purification Products

United States: 800.634.9091

Canada: 800.827.6443

[www.abatement.com](http://www.abatement.com)

Phone 678.889.4200 • Fax 678.889.4201