

HEPA-CARE® USP AIR PURIFICATION SYSTEM.

Quickly & easily upgrade your facility to meet USP 797 air quality requirements.

Installation of HEPA-CARE USP systems in compounding areas can help pharmacies meet existing (ISO Class 8) and proposed (ISO Class 7) USP 797 requirements for air cleanliness. These unique, ceiling mounted systems provide two main benefits: (1) they purify 100% of the air supplied to the area through high-performance HEPA filters, and (2) they create and maintain a positive pressure environment in the area 24/7 to help prevent infiltration of airborne particles from adjoining areas.

- Installs Into a 2' x 2' Drop Ceiling Grid
- Attaches to Existing HVAC Ducting
- Convenient Wall-Mounted Controller
- 99.99% Efficient Pharmaceutical Grade HEPA Filter with Silicone Gel Seal
- Filter Status Indicator Lamps
- Creates & Maintains Positive Pressure 24/7
- Fast, Easy Roomside Filter Replacement
- Class II Medical Device

RECOMMENDED OPTIONS

- Electronic, Wall-Mounted Room Pressure Monitor
- Ceiling-Mounted Germicidal UV Module
- Portable Laser Particle Counter



Wall-mounted Controller



Optional Electronic Room Pressure Monitor



Optional Laser Particle Counter

Abatement Technologies' HEPA-CARE Air Purification Systems are used in more than 3,000 healthcare facilities throughout North America. We would welcome the opportunity to assist you in assessing your facility's needs in meeting USP 797 requirements. Call a "Pure Air For Healthcare.™" expert today.



United States: 800.634.9091

Canada: 800.827.6443

www.hepacareusp.com

605 Satellite Blvd., Suite 300, Suwanee, GA 30024

PHONE 678.889.4200 FAX 678.889.4201