

EASY-INSTALL GERMICIDAL UV LAMP

CAP500 Has Customer-Pleasing Features And Profit Potential

The CAP500 Central Air Purifier is a duct-mounted Germicidal UV Lamp from Abatement Technologies. It includes new high tech features that make it even easier to sell (because it's more attractive to your customers) and even easier to install.

The unit features a high-output 16" UV lamp that has a special filament and internal coating to increase performance over the life of the lamp. Installation requires a single 1" hole and three pilot holes for the mounting screws. Plus, the compact, high impact plastic case fits almost anywhere.

The CAP500 includes a visual indicator to monitor the lamp's status: Green Light: indicates the lamp is operating; Red Light: indicates the lamp needs to be replaced.

All electrical components are sealed to avoid dust contamination and to eliminate customer tampering. An electrical interlock switch disconnects the lamp when the access cover is opened.

More and more customers are aware of the benefits of germicidal UV. This is a product that should be "in-stock" on every service vehicle.

- **Creates a "Killing Zone" Inside Ducting, Kills: Bacteria, Molds, Viruses, VOC's, Cooking, Pet & Tobacco Odors**
- **Lamp is Easily Replaced**
- **Gasketed For a Tight Fit to Duct Surfaces**
- **Lamp Wattage: 39 W**
- **Lamp Output: 1,950 μ W/cm² @ 6" from Lamp**
- **Lamp Life: 1 Year; About 9,000 Hours**
- **Duct Board Adaptor Available**
- **Conforms to UL 1598 & CSA No. 250. Some Competitive Products are Only UL Classified**
- **Case Size: 4 3/4" W x 4 3/4" D x 3 1/4" H**



The CAP500 can be installed on duct board using the duct board adaptor plate.



 **ABATEMENT
TECHNOLOGIES**
Technologically Advanced Air Purification Products

United States: 800.634.9091

Canada: 800.827.6443

www.abatement.com

Phone 678.889.4200 • Fax 678.889.4201