

ECONOMICAL ICRA COMPLIANCE PACKAGES

Convenient, Money-Saving Packages for Meeting ICRA Levels 1, 2, 3 & 4 Requirements*



Use Abatement Technologies® convenient ICRA Compliance Packages to meet CDC and CSA requirements for containing particles during facility construction, renovation and maintenance. These money saving packages include the equipment most commonly needed by facility contractors and in-house maintenance staff to maintain the required air changes per hour (ACH) and negative pressure. Four available kits allow users to choose the one that best meets their specific containment needs.

Each Abatement Technologies ICRA Compliance Package includes a HEPA-AIRE® or PREDATOR® Portable Air Scrubber, a HEPA-CARE® differential-pressure monitor, a HEPA-AIRE® HEPA vacuum and an assortment of useful containment accessories. A complete contents list for each of the standard ICRA packages is shown on the reverse side of this brochure.

*Note: Meeting ICRA Level 4 also requires use of an anteroom enclosure. The AIRE GUARDIAN™ AG3100ARK Anteroom Module from Abatement Technologies meets this requirement.

 **ABATEMENT**
TECHNOLOGIES®
World Class Indoor Air Quality Products

United States: 800.634.9091

Canada: 800.827.6443

www.abatement.com

Phone 678.889.4200 • Fax 678.889.4201

ICRA COMPLIANCE PACKAGE CONTENTS

ICRA Compliance Package Contents				
	IC21000PK*/FK**	IC9000PK*/FK**	IC10000PK*/FK**	IC10000UVPK*/FK**
Maximum Containment Area in Cubic Feet	21,000	9,000	8,000	8,000
Portable Air Scrubber	PAS2400HC	PAS1200HC	PRED1200HC	PRED1200UVHC
Wet/Dry Vac	V8000WD	V8000WD	V8000WD	V8000WD
Room Pressure Monitor Kit (Portable or Fixed, depending on Package)	Room Pressure Monitor	Room Pressure Monitor	Room Pressure Monitor	Room Pressure Monitor
Prefilters (1 cs)	F1821-12	F621-12	F621-12	F621-12
Secondary Filters (1 cs)	H1902-12	H502-6	H502-6	H502UVR-6
Flex Duct & Clamp (1 ea)	H2030-12-10 & H2350-12	H2030-10-12 & H2350-10	H2030-10-12 & H2350-10	H2030-10-12 & H2350-10
6 Mil ICRA Barrier (1 ea)	HCNC1001	HCNC1001	HCNC1001	HCNC1001
Zipwall Adhesive Zippers (2 ea)	HCAZ12	HCAZ12	HCAZ12	HCAZ12
Grill Mask (1 cs) & Dispenser (1 ea)	K1-GM-13 & KM-GM-DS-13	K1-GM-13 & KM-GM-DS-13	K1-GM-13 & KM-GM-DS-13	K1-GM-13 & KM-GM-DS-13

* PK packages contain the PPMT portable differential pressure monitor

** FK packages contain the HCRPM-3N2K fixed room pressure monitor

Portable Air Scrubber Features:

HEPA-AIRE PAS2400HC

- 2 Speeds, 2,100 CFM H / 700 CFM L
- Highest Performance 120 V / 15 A PAS Available
- 6 ACH in an 18,000 to 21,000 Cubic Foot Containment
- 3 to 4 Stages of Filtration
- Zero Bypass Stainless Steel Cabinet
- Detachable Pre-filter Module for Added Portability

PREDATOR PRED1200HC & PRED1200UVHC

- Variable Speed, 300 CFM - 900 CFM
- 6 ACH in a 6,000 - 8,000 Cubic Foot Containment
- 3 to 4 Stages of Filtration
- Virtually Indestructible Rotational Molded Cabinet
- Dual GFCI Receptacles for Daisy-Chaining up to 3 Units
- Germicidal UV Lamps (PRED1200UV Model Only)

HEPA-AIRE PAS1200HC

- Variable Speed, 150 CFM - 900 CFM
- 6 ACH in a 7,500 - 9,000 Cubic Foot Containment
- Up to 4 Stages of Filtration
- Zero Bypass Stainless Steel Cabinet
- Dual GFCI Receptacles for Daisy-Chaining up to 3 Units

Features of Other Key ICRA Kit Components:

V8000WD Wet/Dry Vac

- Air flow, 120 CFM
- Water Lift, 90" W.G.
- Tank Volume, 8 Gallons
- Easy-Emptying Tank
- Complete Tool Kit Included

HCRPM-3N2K Fixed-Mount Room Pressure Monitor

- Easy to Use "Touch Screen" Display
- Energy Efficient, Low Voltage Operation 9-24 Volts
- Auto Calibration
- Easy-to-set Alarm Point
- Low Profile Design
- Accuracy to +/- 0.001" W.G.

PPMT Portable Differential Pressure Monitor

- Up to 16 Days of Operation Under Battery Power
- Ultra-touch Pelican® Case with Plexiglass View Window
- Color Touch Screen Display
- Measurements in Inches of Water Column or Pascals
- Optional Auto Dialer (PM-DIALER) for Remote Notification by Text or Voice
- Accuracy to +/- 3%