

MEGA-PUMP MP3000 WATER EXTRACTION SYSTEM

High Performance Technology for Extracting Standing Water



- **Versatile:** A Sump Pump And A Wet/Dry Vacuum In One Compact Unit
- **Powerful:** Extracts Up To 3,600 Gallons Per Hour
- **Economical:** 60 GPM Capacity Cleans Up Large Volume Leaks & Spills Faster
- **Efficient:** Removes All Standing Water
- **Clean:** Separates Solids From Discharge Water

MEGA-PUMP Feature	Water Extraction Benefit
Three operating modes - combination pump & wet/dry vacuum, pump only, & wet/dry vacuum only	One versatile piece of equipment that handles both jobs exceptionally well & saves time & money
Powerful vacuum & water lift	Clean large leaks & spills faster & more easily
The ability to discharge water up to 23 feet vertically or 300 feet horizontally	The extraction power needed to effectively pump out basements & other below ground locations
The ability to completely remove standing water down to the floor	Ordinary sump pumps leave at least 1 inch to 1.5 inches of standing water
Stainless steel filter basket for solids	Cleaner discharge water
The ability to operate in either a “vacuum only” or “pump only” mode	Filtered liquids can be pumped from the vacuum tank into another container such as a 55-gallon drum
“Tilt & dump” recovery tank (also lifts out)	Faster & easier removal of captured contents
Lightweight, low-profile design & built-in cart	Exceptionally easy to roll to & around the job site

More Productive & Efficient Water Extraction Technology



Abatement Technologies MEGA-PUMP 3000 Specifications

Pump Motor	0.5 HP, Draws 3 Amps @ 115 Volts AC/60 Hz
Pump Capacity	60 GPM, 23 Ft Vertical Discharge & 300 Ft Horizontal Discharge
Vacuum Motor	1.6 HP, Draws 8.5 Amps or Less @ 115 Volts AC/60Hz
Vacuum Capacity	50 GPM, 140 CFM & 105 Inches Static Lift
Canister	Stainless Steel, with 19 Gallon Holding Capacity
Suction (Inlet) Hose	1.5 Inch Diameter x 13 Feet Long, Crush Proof (Included)
Standard Tool Kit	Suction Hose, Curved Wand, 2-Piece Extension Wand, Squeegee Tool & 1.5 Inch Diameter NPT Discharge Hose Fitting
Discharge Hose	Heavy Duty 1.5 Inch Diameter x 25, 50 or 100 Feet Long (Sold Separately)
Power Cord	Attached, 14/3 AWG with Grounded Plug, 35 Feet Long
Weight/ Dimensions	73 Pounds, 23 Inches Wide x 24 Inches Deep x 38 Inches High

CAUTION: The Mega-Pump 3000 is not a HEPA vacuum and is not intrinsically safe. It is not suitable for picking up hazardous dusts. Do not use the Mega-Pump 3000 to pick up hot or glowing materials (ashes/cigarettes), flammable liquids (gasoline, solvents, acids, alkalis etc.) or explosive dusts.



United States: 800.634.9091

Canada: 800.827.6443

Overseas: 678-889-4200

www.abatement.com