

The PAS5000 Portable Air Scrubber

Powerful, Industrial and Commercial Air Purification



Solid Rivet Aircraft Construction

True 99.97% HEPA Filtration

Airflow up to 4,000 cfm

5" Filter Status Gauge

Digital Hour Meter

Powerful

The PAS5000 is designed to handle the largest industrial and commercial air cleaning applications. Its five-horsepower, 230-volt single-phase motor and multi-inlet blower deliver peak airflow of about 4,000 cubic feet per minute (cfm). Maximum current draw is 21 amps on a 230-volt/30-amp-60-hertz power supply.

Durable

The PAS5000 is designed for years of reliable operation under even the toughest job conditions. Tough, galvanized steel cabinetry, solid rivet fasteners and reinforced caster mounting rails on the underside of the cabinet insure cabinet strength, integrity and rigidity.

Efficient

Two pleated filters are standard. VAPOR-LOCK® carbon filters for gasses and odors are also available. The dual 2,000-cfm HEPA filters are 100% tested and certified to provide efficiency of at least 99.97% @ 0.3 microns, in accordance with stringent IEST-RP-CC001-4 requirements. Critical internal seams are sealed with neoprene gaskets to prevent bypass.

Portable

At only 26.5 inches wide the PAS5000 fits easily through standard doorways. Four extra heavy-duty, 5-inch-diameter by 2-inch-wide casters (2 fixed and 2 locking swivels) provide mobility and maneuverability.

Versatile

Filtered air can be ducted and exhausted through a containment barrier to create a negative pressure environment, or recirculated back into the same area. Optional dual inlet manifolds and inlet ducting can be used to simultaneously access two different remote areas.



United States: 800.634.9091

Canada: 800.827.6443

Overseas: 678-889-4200

www.abatement.com