

The PAS5000 Portable Air Scrubber

Powerful Industrial and Commercial Air Purification



Solid Rivet “Aircraft” Construction.

Carbon Filters for Odor Removal.

True 99.97% HEPA Filtration.

Airflow up to 4,000 cfm.

5” Filter Status Gauge.

Hour Meter.

Powerful

The PAS5000 is designed to handle the largest industrial and commercial air cleaning applications. Its five-horsepower, 230-volt single-phase motor and multi-inlet blower deliver peak airflow of about 4,000 cubic feet per minute (cfm). Maximum current draw is 23 amps on a 230-volt/30-amp/60-hertz power supply.

Durable

The PAS5000 is designed for years of reliable operation under even the toughest job conditions. Tough, galvanized steel cabinetry, solid rivet fasteners and reinforced caster mounting rails on the underside of the cabinet ensure cabinet strength, integrity and rigidity.

Efficient

Granular carbon prefilters for gasses and odors are standard; optional particulate prefilters are also available. The dual 2,000-cfm HEPA filters are 100% tested and certified to provide efficiency of at least 99.97% @ 0.3 microns, in accordance with IEST-RP-CC001.3 requirements. Critical internal seams are sealed with neoprene gaskets to prevent bypass.

Portable

At only 26.5 inches wide the PAS5000 fits easily through standard doorways. Four extra heavy-duty, 5-inch-diameter by 2-inch-wide casters (2 fixed and 2 locking swivels) provide mobility and maneuverability.

Versatile

Filtered air can be ducted and exhausted through a containment barrier to create a negative pressure environment, or recirculated back into the same area. Optional dual inlet manifolds and inlet ducting can be used to simultaneously access two different remote areas.

**U.S. Toll Free:
800-634-9091**



**Canada Toll Free:
800-827-6443**

Abatement Technologies, Inc., 605 Satellite Blvd., Suite 300 Suwanee, GA 30024
www.abatement.com