

“DAISY CHAIN” FOR MORE CLEANING POWER.

Connect up to 5 HEPA-AIRE® PAS600's to produce up to 3,000cfm.

The new HEPA-AIRE PAS600 model Portable Air Scrubber from Abatement Technologies is now even more versatile. Up to 5 units can be “daisy-chained” to produce up to 3,000cfm on a single 15 amp circuit! That gives you the flexibility to add units according to the requirements of the job.

CONVENIENCE FEATURES

- New Two-Plug GFCI: “Daisy Chain” Multiple Units on One 15 Amp Circuit
- “Stackability”: Saves Space & Time in Use, Transport & Storage
- New “Tip-Out” Prefilter Access Door: Protects Prefilters / Fast Filter Change
- Filter Replacement Indicator Lamp
- Recessed Control Panel: Protects Components
- Lightweight: Just 46 lbs, Incl. Filters
- Top-Mounted Carrying Handles
- Compact: 27.75” L x 16” W x 17.125” H
- Caster Cart (Optional Accessory)
- 8” Inlet Collar (Optional Accessory)

PERFORMANCE & SAFETY FEATURES

- Powerful: Up to 600cfm per Unit
- Variable Speed Control
- Efficient: Each HEPA is Tested & Certified / “Zero-Bypass” Cabinet Design
- Optional Vapor-Lock® Carbon Filter
- Pop-Out Circuit Breaker & GFCI
- Attached 8” Exhaust Collar
- ETL Certified For Electrical Safety
- Corrosion-Resistant Stainless Steel



Call us today for more information. One of our HEPA-AIRE PAS Product Experts can assist you in selecting the equipment & accessories best suited to your business needs.

 **ABATEMENT
TECHNOLOGIES**
Technologically Advanced Air Purification Products

United States: 800.634.9091

Canada: 800.827.6443

www.abatement.com

605 Satellite Blvd., Suite 300, Suwanee, GA 30024
PHONE 678.889.4200 FAX 678.889.4201